


Tefal®



INGENIO BC54xx

Instruction manual – Notice d'utilisation – Gebruiksaanwijzing –
Bedienungsanleitung – Manuale di istruzioni – Manual de instrucciones
– Manual de instruções – Εγχειρίδιο οδηγιών – Kullanma kılavuzu –
Instrukcja obsługi – Uživatelská příručka – Használati útmutató –
Návod na použitie – Manual de instrucţiuni – Uputstvo za upotrebu –
Upute za uporabu – Ръководство с инструкции – Руководство по
эксплуатации – Priročnik z navodili – Посібник з експлуатації

www.tefal.com

1820004165

FR : Balance de cuisine / NL : Keukenweegschaal / DE : Küchenwaage / IT : Bilancia da cucina
EN : Kitchen scale / ES : Báscula de cocina / PT : Balança de cozinha / EL : Ζυγαριά κουζίνας
TR : Mutfak tartısı / DA : Køkkenvægt / FI : Keittiövaaka / HR : Kuhinjska vaga
RU : кухонные весы / PL : Waga kuchenna / CS : Kuchyňská váha / HU : Konyhai mérleg
SK : Kuchynská váha / RO : Cântar de bucătărie / SR : Kuhinjska vaga / SL : Kuhinjska tehtnica
AR : ميزان للمطبخ / BG : Кухненска везна / UK : Ваги кухонні
ET : köögikaal / LT : Virtuvės svarstyklės / LV : Virtuves svāri

ON

To START
PRESS 2 sec

0
g

Press 2" 

The diagram illustrates the four steps to use the TARE function on a digital scale:

- 1. TARE:** The scale is empty, and the display shows **0** g.
- 2. Weighing:** A container is placed on the scale, and the display shows **246** g.
- 3. Tare:** The container is pressed (indicated by a hand icon and the word "Press"), and the display shows **0000** g.
- 4. Weighing:** The container is filled with material, and the display shows **20** g.

UNIT

1

Diagram 1 shows the first step of unit selection. A hand is pressing the 'g' button on the side of the scale. The digital display shows '0' with a small 'g' below it. An arrow points from the button to the display.

g

Press

2

Diagram 2 shows the second step of unit selection. A hand is pressing the 'fl.oz.' button on the side of the scale. The digital display shows '00' with 'fl.oz.' below it. An arrow points from the button to the display.

fl.oz.

Press

3

Diagram 3 shows the third step of unit selection. A hand is pressing the 'lb.oz.' button on the side of the scale. The digital display shows '0:00' with 'lb' and 'oz' below it. An arrow points from the button to the display.

lb.oz.

Press

4

Diagram 4 shows the fourth step of unit selection. A hand is pressing the 'ml' button on the side of the scale. The digital display shows '0' with 'ml' below it. An arrow points from the button to the display.

ml

Press

Press

Press

Press

3 LR03 AAA

The diagram illustrates the correct battery insertion for the 3 LR03 AAA batteries. It includes a warning symbol, a crossed-out R03 HR03 battery, and the correct LR03 Alkaline Batteries.

MAX

2










[illegible]

3

4



111



OK